

© CONTENTS ©

Chapter 1. INTRODUCTION

1.1 Features.....	1-1
-------------------	-----

Chapter 2. SPECIFICATIONS

2.1 General Specifications	2-1
2.2 Performance Specifications	2-2
2.3 Names of Parts and Functions	2-3
2.4 PID Control Action	2-4
2.4.1 Processing Type	2-4
1) Velocity Type Processing	2-4
2) Measured Value Derivative Type (Pre-Derivative Type)	2-4
2.4.2 Control Actions	2-5
1) Proportional Action (P Action)	2-5
2) Integral Action (I Action)	2-7
3) Derivative Action (D Action)	2-9
4) PID Action	2-10
5) PID Processing Expression	2-10
6) Forward/Reverse Actions	2-11

Chapter 3. INSTALLATION

3.1 Installation Ambience	3-1
3.2 Handling Precautions	3-1

Chapter 4. BUFFER MEMORY CONFIGURATION AND FUNCTIONS

4.1	Buffer Memory Configuration	4-1
4.1.1	K7F-PIDA Buffer Memory	4-1
4.1.2	K4F-PIDA Buffer Memory	4-2
4.2	Functions of Buffer Memory	4-3
4.2.1	Specifying Loop Enable/Disable	4-3
	(K7F-PIDA : addresses 0 and 1, K4F-PIDA : address 0)	
4.2.2	Specifying Auto/Manual Processing	4-3
	(K7F-PIDA : addresses 2 and 3, K4F-PIDA : address 1)	
4.2.3	Specifying Forward/Reverse Action	4-4
	(K7F-PIDA : addresses 4 and 5, K4F-PIDA : address 2)	
4.2.4	Specifying SET Data Enable/Disable	4-4
	(K7F-PIDA : addresses 6 and 7, K4F-PIDA : address 3)	
4.2.5	Loop Run Information	4-5
	(K7F-PIDA : addresses 8 and 9, K4F-PIDA : address 4)	
4.2.6	Setting PID Control Data	4-5
4.2.7	Outputting Manipulated Value	4-6
	(K7F-PIDA : addresses 202 and 203, K4F-PIDA : addresses 53 to 60)	
4.2.8	Setting Error Information	4-6
	(K7F-PIDA : addresses 203 to 265, K4F-PIDA : addresses 61 to 68)	

Chapter 5. DEDICATED INSTRUCTIONS FOR SPECIAL MODULES (Read from/Write to Buffer Memory)

5.1	Read to Buffer Memory ...GET, GETP	5-1
5.2	Write to Buffer Memory ... PUT, PUTP	5-2

Chapter 6. PROGRAMMING

6.1 Basic Programming	6-1
6.1.1 K7F-PIDA	6-1
6.1.2 K4F-PIDA	6-2
6.2 Application Programming	6-3
6.2.1 A Program for Controlling an Electric Furnace (with Applying the A/D Conversion Module, PID Control Module and D/A Conversion Module)	6-3
6.2.2 A Program for Control Using a RTD (with Applying the RTD Input Module, PID Control Module and D/A Conversion Module.)	6-6
6.2.3 A Program for Control Using a Thermocouple (with Applying the TC Input Module, PID Control Module and D/A Conversion Module)	6-8

Chapter 7. TROUBLESHOOTING

7.1 Errors Indicated by RUN LED Flickering	7-1
7.2 Troubleshooting Procedure	7-1
7.2.1 RUN LED Flickering	7-1
7.2.2 RUN LED Off	7-1
7.2.3 Unreadable Processing Result of PID Control Module	7-2
7.2.4 Run LED of Enabled Loops Off	7-2
7.2.5 PID Control Module Hardware Defect	7-2

Chapter 8. DIMENSIONS

8.1 K7F-PIDA Dimensions	8-1
8.2 K4F-PIDA Dimensions	8-2