

# ◎ CONTENTS ◎

## Chapter 1. INTRODUCTION

1.1 Features .....	1-1
--------------------	-----

## Chapter 2. SYSTEM CONFIGURATION

2.1 Example of System Configuration .....	2-1
---	-----

## Chapter 3. SPECIFICATIONS

3.1 General Specifications .....	3-1
3.2 Performance Specifications .....	3-2
3.3 Names of Parts and Functions .....	3-3
3.3.1 K7F-AT4A .....	3-3
3.3.2 K4F-AT3A .....	3-4
3.3.3 Names of Parts and Functions .....	3-5
3.4 Setting Procedure for Each Function .....	3-7
3.4.1 Setting the Setting Range Selection Switch .....	3-7
3.4.2 Adjusting the Volume .....	3-8

## Chapter 4. PROGRAMMING

4.1 I/O Signals .....	4-1
4.1.1 K7F-AT4A .....	4-1
4.1.2 K4F-AT3A .....	4-1
4.1.3 Example for Executing the Analog Timer T00 by Program .....	4-2
4.2 Program for Comparing and Outputting the Setting Times of Analog Timers .....	4-3
4.2.1 System Configuration .....	4-3
4.2.2 Initial Settings .....	4-3
4.2.3 Program Description .....	4-3
4.2.4 Program .....	4-4

## Chapter 5. INSTALLATION

5.1	Installation .....	5-1
5.1.1	Installation Ambience .....	5-1
5.1.2	Handling precautions .....	5-1

## Chapter 6. TROUBLESHOOTING

6.1	Error Code .....	6-1
6.2	Troubleshooting Procedure .....	6-2
6.2.1	RUN LED off .....	6-2
6.2.2	The Contact Indication LED for the Timer Operation does not Turn on When the Timer Starts its Operation .....	6-3
6.2.3	The Operation Contact does not Turn on Though the Setting Time has Passed after the Start of the Timer .....	6-4

## Chapter 7. TEST RUN

7.1	Run Procedure .....	7-1
-----	---------------------	-----

## Chapter 8. DIMENSIONS

8.1	Dimensions .....	8-1
8.1.1	K7F-AT4A .....	8-1
8.1.2	K4F-AT3A .....	8-2